



# DAHUA Email setting



1. Log in to Gmail to set the path--Forwarding and POP/ IMAP --- Enable POP and IMAP ---Save .



2. Choose Manage your Google Account.



3. Enter Security Management---Enable 2-Step Verification--TURN ON.



4. Enter Security Management---Click App passwords--Setting select the app and device for which you want to generate the app password.

Click App passwords App passwords settings.

Google Account Search Google Account

Home  
Personal Info  
Data & personalisation  
**Security 1**  
People and sharing  
Payments and subscriptions

### Security

Settings and recommendations to help you keep your account secure

**Security issues found**  
Protect your account now by resolving these issues

Secure account

**Signing in to Google**

Password Last changed 6 Apr 2014 >

2-Step Verification  On >

2 App passwords None >

App passwords settings.

← App passwords

App passwords let you sign in to your Google Account from apps on devices that don't support 2-Step Verification. You'll only need to enter it once so you don't need to remember it. [Learn more](#)

You don't have any app passwords.

Select the app and device for which you want to generate the app password.

Select app  
Mail  
Calendar  
Contacts  
YouTube  
Other (Custom name)

Select device ▼

GENERATE

Generated app password

Email Login password

Your app password for your device  
avvr [dots] pekx mppt


How to use it

Go to the settings for your Google Account in the application or device you are trying to set up. Replace your password with the 16-character password shown above. Just like your normal password, this app password grants complete access to your Google Account. You won't need to remember it, so don't write it down or share it with anyone.


Done

Done

5. Open the IE browser and log in camera web.



6. log in camera web ,enter camera Setting screen.click"setting-network-SMTP(Email)".



7. Set mailbox content.

- ① SMTP Server:The email server usually is "SMTP.Gmail.COM".
- ② Port:The general port is 465, other specific ports need to check the settings of the mail.
- ③ Use name:User account.
- ④ Password:Authorization code required to log in to third-party software by email.
- ⑤ Sender:user sender.

- ⑥ Authentication: Use the required verification method.
- ⑦ Title: The file name of the sent mail.
- ⑧ Mail Receiver: Enter the email address to accept the email, click "+" to save the content. Click healthy Email and setting update period. Save and test settings.

